
BRUCK LIGHTING SYSTEMS 15774 Gateway Circle Tustin, CA. 92780 www.brucklighting.com For more assistance with technical questions please call our technical support staff at (714) 259-9959. You can also contact us by email at info@brucklightingsystems.com.

BRUCK

ENZIS INSTALLATION INSTRUCTIONS



LIGHTPOINT II ART. NO. 140 760bz bronze, 3 1/2"

matte chrome, 3 1/2"

140 760mc

TECHNICAL DATA

Description: Light Fixture Design: Jorg Westerheide


▲ IMPORTANT SAFETY INSTRUCTIONS ⊿

- 1. THIS PRODUCT MUST BE INSTALLED BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED, IN ACCORDANCE WITH LOCAL NEC CODE.
- 2. FOR USE WITH ENZIS RAIL NETWORK ONLY.
- 3. The Enzis rail system is not intended for use with a power supply cord or convenience receptacle adaptor. This rail system is to be supplied by Bruck Lighting.
- 4. Do not install the Enzis rail system in damp or wet locations.
- 5. Do not install any part of a rail system less than 5 feet above the floor.
- 6. Do not install any fixture assembly closer than 6 inches from any curtain, or similar combustible material.
- 7. Disconnect electrical power before adding to or changing the configuration of the rail.
- 8. Do not attempt to energize anything other than lighting rail fixtures on the rail. To reduce the risk of fire and electric shock, do not attempt to connect power tools, extension cords, appliances, and the like to the rail.
- 9. This track system MUST BE HARD WIRED. For all the wire connections, use Listed Wire Nuts.
- 10. Do not connect a rail to more than one circuit unless the rail is constructed so that it can be used with more than on circuit. Check with a qualified electrician. Although the rail lighting system may seem to operate acceptably, a dangerous overload of the neutral may occur and result in a risk of fire.
- 11. Secondary connections must be clean and tight to avoid arcing and overheating!
- 12. Power Feed must be 3 inches away from any support and 6 inches away from fixture.
- 13. Warranty is void in case of unauthorized modifications and/ or improper use.

SAVE THESE INSTRUCTIONS AND REFER TO THEM WHEN ADDITIONS TO OR CHANGES IN THE TRACK CONFIGURATION ARE MADE

CONTENTS OF DELIVERY

1 Lightpoint II Fixture



USER MANUAL

INSTALLING LIGHTPOINT II

- Place Lightpoint II Fixture onto Enzis track.

- Secure Lightpoint II by tighten thumb screws (A) with phillips head screwdriver, #3 is the recommended size to use.

