COASTER® FINE FURNITURE

4358

MAPLE DINING CHAIR WITH CUSHION SEAT

ASSEMBLY INSTRUCTION

COASTER FINE FURNITURE



www.coastercompany.com

ASSEMBLY INSTRUCTION

ASSEMBLY TIPS :

1. Remove hardware from plastic bag and sort by size.
2. Please check to see that all hardware and part are present prior start of assembly.
3. Please follow attached intructions in the same sequence as numbered to assure fast & easy assembly.

⚠ Warning !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

PARTS IDENTIFICATION:

A. BACK MEMBER  2PCS

B. FRONT MEMBER  2PCS

C. SIDE PANEL  4PCS

D. CUSHION SEAT 2PCS

HARDWARE PACKAGE:

NO	DESCRIPTION	FIGURE	QTY
E	ALLEN KEY M4 X 110MM		1PC
F	JCBC BOLT M6 X 50MM		12PCS
G	SPRING WASHER 1/4"		12PCS
H	PH CBS SCREW #8 X 1"		8PCS

STEP 1





STEP 2



STEP 3





BOTTOM VIEW