


912097

# **Assembly Instructions**

**Patent Pending** 


- 1) Remove the lamp shade and the supporting rod ( C ) from the box.(Fig.1)
- 2) Put the shade on a flat surface, and place supporting rod ( C ) into top ring (A) as shown. (Fig.2)
- 3) Place the other end of supporting rod ( C ) into bottom ring (B) as shown.(Fig.3)
- 4) Repeat steps 2 and 3 to install other supporting rods.
- 5) Make final adjustments.(Fig.4)







## **ASSEMBLY INSTRUCTIONS**



#### FOR ASSEMBLY THE LAMP BODY

- 1.BEING CAREFUL NOT TO TWIST THE POWER CORD DURING ASSEMBLY, TIGHTEN THE COLUMN ONTO BASE SECURELY. UNTIL THE POWER CORD.GRAB THE POWER CORD AT THE BASE OF THE LAMP AND PULL THE EXCESS CORD THROUGH THE BASE.
- 2. FASTEN THE SOCKET ASSEMBLY ONTO COLUMN.
- 3. INSERT THE HARP PRONGS INTO THE SADDLE AND SLIDE THE RETAINING COVERS JOINTS TO SECURE THE HARP.
- 4. UNSCREW THE FINIAL FROM THE HARP. THEN PLACE THE SHADE ONTO HARP AND SECURE WITH THE FINIAL.

NOTE: SEE SHADE ASSEMBLY INSTRUCTIONS
(ON THE OTHER PAGE) TO ASSEMBLE
SHADE BEFORE ATTACHING TO LAMP

#### **NEED ASSISTANCE?**

Call **4D CONCEPTS** directly for parts or assembly assistance. Individual stores do not stock parts
Call our Toll-free number 5 days a week except holidays:
Monday through Friday **8:00am** to **5:00pm**Pacific Standard Time

# 1- 888- 310- 4DCO or 1- 888- 310 4326 IMPORTANT: Before calling please have the model number and the

packing code number ready for our customer service representatives. You will find the model number printed on the carton label and the packing code printed in black ink on the side of the carton.

Model: 12097 Packing code: 6-49423-12097-3

It is important that you retain the model number and the packing code along with the original receipt of purchase for future reference.

**MADE IN CHINA** 

### IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.