



FIVE PIECE PLACE SETTING

1101030 five piece plate setting 550.00

1101080 cup & saucer 7 oz

160.00



1101617 bread & butter plate 6 ¾" 110.00



1101620 salad/dessert plate* 7 ½" 120.00



1101627 dinner plate 10 ¾"



ner plate %" 160.00

Blue Fluted Plain

CUPS & SAUCERS

1101092

cup & saucer, high handle

8 ¾ oz

200.00

1101106

soup cup & saucer, covered

11 ¾ oz

470.00

1101077

tea cup & saucer

6 ½ oz

160.00

CHILDREN'S

1101032

baby set with cup and soup plate

5 & 12 oz.

300.00





1101126 coffee pot

64 oz

550.00

1101141 tea pot

475.00 64 oz

1101153 sugar bowl, covered

210.00 5 ¼ oz

1101394 large creamer

6 oz 200.00











Blue Fluted Plain

Accessories

1101575 bowl, small

11 ¾ oz

160.00

1101577

bowl, medium

27 oz

280.00



1101579 bowl, large

47 ½ oz


550.00





1101563 sauce boat on fixed stand

425.00 15 ¾ oz



1101375 large oval platter 14 1/4" 530.00







1101442 pitcher 32 oz

300.00



130.00



130.00



1101605 soup plate 9"

1101204 covered butter dish*

415.00 8"

1101357 leaf accent dish 9"

1101580 flower bowl 10 oz







