

## COZY-FEET Instructions

When you're ready to use, insert two AA batteries, not included, in each battery pack (total four AA batteries). Insert the right and left in the appropriate shoes, printed side facing up. Remove the plastic backing from the adhesive if Cozy-Feet will stay permanently in these shoes, otherwise leave the backing in place. Cozy-Feet will heat up right away to a comfortable (not noticeably "hot") 98° body temp.

Remove the batteries when you no longer want heat. For extended use, carry spare batteries. In fact, rechargeable batteries are recommended. To clean Cozy-Feet, detach the batteries and wipe with a cloth.

**REORDER part #CF.**

300 N. Elizabeth St. Chicago, IL 60607 USA  
Phone 312-226-2473  
FAX 312-226-2480  
E-mail [sales@indus-tool.com](mailto:sales@indus-tool.com)  
[www.indus-tool.com](http://www.indus-tool.com)