



Dining Table 48" Ø

Assembly Instructions

Parts Included:

Top Panel	1 pc.
Base	1 pc.
Glass	1 pc.

Hardwares:

Stainless Steel Bolts	4 pcs
Stainless Steel Washers	4 pcs
Plastic Bolt Cover	4 pcs
Allen Wrench	1 pc



Assembly:

1. Unpack the Components. Base on the above list components is complete.
2. Place the Top Panel in upside down position on the protected floor.
3. Align both holes on the Base to the Top Panel and fix together using a Stainless Steel Bolts
See Figure .01 below
4. Tighten all Bolts using the Allen Wrench provided.
Then cover the bolts with the Plastic bolt Cover
5. Then place the item in correct position to attach the Glass Top.

FIGURE 01

