


# ASSEMBLY INSTRUCTIONS

## ITEM NO: BO-991GT

1. CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE AND LAY THEM UP AS PER THE SKETCH.
2. SCREW THE DECORATIVE PART (B) INTO THE BASE (A).
3. SCREW BOTTOM TUBE (C), GLASS TRAY (D), UPPER TUBE (E) AND SOCKET PART (F) INTO THE DECORATIVE PART (B) IN TURN.
4. PUT THE HARP (G) ONTO THE SADDLE OF THE SOCKET PART (F).
5. PUT THE SHADE (NOT INCLUDED) ONTO THE HARP (G) AND FIX WITH THE FINIAL (H), THEN ADJUST THE SHADE (NOT INCLUDED) HORIZONTALLY.
6. INSERT THE POLARIZED PLUG INTO OUTLET , TURN ON THE SWITCH AND ENJOY YOUR LAMP.



WATTAGE: 3-WAY 150W TYPE A (EX BULB)

## IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

**SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**