

ASSEMBLY INSTRUCTIONS


ITEM NO: BO-587TR

1. CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE AND LAY THEM UP AS PER THE SKETCH.
2. SCREW POLE (B) ONTO BASE (A), CONNECTOR (C) INTO POLE (B), POLE (D) ONTO CONNECTOR (C) AND DECORATIVE FONT (E) INTO POLE (D).
3. PUT SHADE (F) ONTO THE SOCKET OF DECORATIVE FONT (E), AND TIGHTEN THE SHADE WITH RING (G).
4. CHECK IF DECORATIVE FOUNT (E) IS FACING SAME DIRECTION AS THE BASE .IF NOT LOOSEN THE NUT UNDERNEATH BASE (A) TO MAKE NECESSARY ADJUSTMENT.
5. INSERT THE POLARIZED PLUG INTO WALL OUTLET, TURN ON THE SWITCH AND ENJOY YOUR NEW LAMP.

Use 3-way 150 Wattage (Maximum) type A bulb (bulb not included)

IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.



***SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE**

323780B