


Installation Instruction

Item No: BO-935



1. Carefully unpack and take out the parts as picture shown.
2. Squeeze harp (C) together and insert into saddle (D) tightly.
3. Attach the shade (B) onto harp (C), then screw the finial (A).
4. Insert the fish pole (E) into hole of fish basket (F).

Important Safety Instruction

This portable lamp has a polarized plug (One blade is wider than the other) as a safety feature to reduce the risk of the electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit in the outlet, reverse the plug. If it still does not fit, consult a qualified electrician. Never use an extension cord unless the plug can be fully inserted. Do not alter the plug.

Note: 120V/ 150W

★ **Keep this instruction for future reference**