


WANDA DESK LAMP
MODEL # 3297-01



PLEASE READ AND SAVE THESE INSTRUCTIONS:

- 1.REMOVE ALL PARTS FROM PACKAGING AND LAY ON A FLAT SURFACE.
- 2.CONNECT THE TRANSFORMER (A) TO THE CORD AND PLUG IN.



MAINTENANCE:

LED / 7 Watt (Included)

To clean lamp, wipe with clean, dry cloth.



21 Penn Plaza #909 New York, NY 10001
Tel : (212) 736 4440 Fax : (212) 736 4806
www.adessohome.com