


## Bright Baking Set Assembly Instructions

Item #63316

To order replacement parts, please visit www.kidkraft.com



Before calling customer service, please locate the batch code number (example: 105906/65006/04) found on the bottom or back of your product.

**Customer Service** 1-800-933-0771 www.kidkraft.com