

Model: Bottom Drawer

Drawer work with Stand S2030 and S2033 only,
available at three widths

DR25- H01	Dark Cherry
DR25- F08	Cinnamon
DR33- H01	Dark Cherry
DR33- F08	Cinnamon
DR37- H01	Dark Cherry
DR37- F08	Cinnamon

Model	Widths
DR25	18-1/8"(46cm)
DR33	26-3/4"(68cm)
DR37	30-11/16"(78cm)

Install Bottom Drawer

Step 1.

Release the lever on each side, according to the arrows and pull out drawer.

Step 2.

screw to the side of the stand

