



INSTALLATION INSTRUCTIONS

- 1. Before beginning the installation, carefully unpack and identify all parts, referring to illustration.
- 2. Turn the electrical power to installation point OFF at circuit breaker.
- 3. Postion GLASS PANELS inside of CAGE. Lift CAGE with GLASS upward and align the holes on top edge of CAGE with mounting holes on the bottom edge of FIXTURE COVER. Secure them together by threading LOCK SCREWS onto the mounting holes on the FIXTURE COVER. Hand tighten until snug.
- 4. Locate the UNIVERSAL CROSSBAR and secure to OUTLET BOX with (2)OUTLET BOX SCREWS(not supplied).
- 5. Make the connections: (Quoizel recommends 2 people for this step)
 Use wire connectors (not supplied) connect the HOUSE GROUND to the
 FIXTURE GROUND WIRE; attach the HOUSE WHITE WIRE to FIXTURE
 WHITE (or RIBBED SIDE) SUPPLY WIRE; connect the HOUSE BLACK
 (or RED) WIRE to the FIXTURE BLACK (or SMOOTH SIDE) WIRE. Wrap
 each connection with approved electrical tape.
- 6. Carefully tuck all wires into the WALL MOUNTED OUTLET BOX and position the fixture over the outlet box. Align the HOLES in the BACKPLATE with the (2) MOUNTING SCREWS attached to the UNIVERSAL CROSSBAR. Pass the fixture over the (2)MOUNTING SCREWS and secure against by threading (2)MOUNTING BALLS onto end of screw. Tighten until snug.
- 7. Install bulb(s) referring to fixture markings and/or labels for maximum wattage.
- 8. Refer to Page 2 for fixture caulking instructions.
- 9. Restore power to the installation point ON. Retain this sheet for future reference.

IF IN DOUBT ABOUT ELECTRICAL INSTALLATION, CONSULT A LICENSED ELECTRICIAN!



WALL SURFACE MOUNTED OUTDOOR FIXTURE CAULKING INSTRUCTIONS

With the OUTDOOR FIXTURE properly installed in accordance with supplied assembly/installation instructions, proceed with caulking instructions below.

Note: Be sure EXTERIOR WALL SURFACE and FIXTURE BACKPLATE are free to dirt to caulking. Using EXTERIOR GRADE CAULK, start on one side of FIXTURE BACKPLATE and follow contour, were the FIXTURE BACKPLATE meets the EXTERIOR WALL SURFACE upward. Proceed to caulk over top of backplate and down other side. **DO NOT CAULK BOTTOM OF FIXTURE BACKPLATE** to ensure proper moisture drainage.

