


INSTALLATION INSTRUCTIONS

- 1. Before beginning the installation, carefully unpack and identify all parts referring to the illustration.
- 2. Turn the electrical power to installation point OFF at circuit breaker.
- 3.Slip down the GLASS PANEL to the inside of the CAGE. Locate the TABS onto the top edge of the GLASS PANEL and match the holes on them with the mounting holes on the top edge of the CAGE. Use screw driver, thread the LOCK SCREWS into the mounting holes and hand tighten until snug to secure the GLASS PANEL.
- 4. Install the bulb referring to fixture markings and/or labels for maximum wattage.
- 5.Lift the CAGE with GLASS PANELS upward to attach the bottom of the FIXTURE HOOD and make the holes on the top edge of the CAGE match the mounting holes on the bottom of the FIXTURE HOOD. Secure them together with the LOCK SCREWS. Hand them until snug with screw driver.
- 6.Place the CROSSBAR on the BACKPLATE and align the holes in the BACKPLATE with a set of threaded holes in the CROSSBAR. Install the (2) MOUNTING SCREWS in the aligned threaded holes on the CROSSBAR. Next, mount the CROSSBAR to the outlet box with (2)OUTLETBOX SCREWS (not provided).
- 6. Make the connections: Use wire connectors(not supplied) connect the HOUSE GROUND to the FIXTURE GROUND WIRE; attach the HOUSE WHITE WIRE to FIXTURE WHITE (or RIBBED SIDE) SUPPLY WIRE; connect the HOUSE BLACK (or RED) WIRE to the FIXTURE BLACK(or SMOOTH SIDE) WIRE. Wrap each connection with approved electrical tape.
- 7. Carefully tuck all wires into the WALL MOUNTED OUTLET BOX and position the fixture over the outlet box. Align the HOLES in the BACKPLATE with the (2) MOUNTING SCREWS attached to the UNIVERSAL CROSSBAR. Pass the fixture over the (2) MOUNTING SCREWS and secure against by threading (2) MOUNTING BALLS onto end of screw. Tighten until snug.
- 8. Refer to Page 2 for fixture caulking instructions.
- 9. Restore power to the installation point ON. Retain this sheet for future reference.



EXTERIOR CAULK

EXTERIOR CAULK

EXTERIOR CAULK

WALL SURFACE MOUNTED OUTDOOR FIXTURE CAULKING INSTRUCTIONS

With the OUTDOOR FIXTURE properly installed in accordance with supplied assembly/installation instructions, proceed with caulking instructions below.

Note: Be sure EXTERIOR WALL SURFACE and FIXTURE BACKPLATE are free to dirt to caulking. Using EXTERIOR GRADE CAULK, start on one side of FIXTURE BACKPLATE and follow contour, were the FIXTURE BACKPLATE meets the EXTERIOR WALL SURFACE upward. Proceed to caulk over top of backplate and down other side. **DO NOT CAULK BOTTOM OF FIXTURE BACKPLATE** to ensure proper moisture drainage.

> IS-HC8409 Page2of2 2007-02-28