Lamp data is based on manufacturers published information recalculated at approximately 12 volts.

2,555	33	000,8	4.2	Z1-4	9732 NON3X	ХВАТ			
2,450	97	2,000	8.5	4-12	9729	ЗЕАТ			
2,300	23	000'6	4.0	4-12	8276	ЗЗАT			
2,400	٩٤	000,61	7.2	Z1-4	VENON 9731	ACCENT			
2,200	8	20,000	۲.2	6-12	7276	ACCENT			
(TEMP'K) COLOR APPROX.	APPROX. LIGHT (LUMEN)	RATED LIFE (HOURES)	CONSUMED WATTS	(INCHES) SPACING SUGGESTED	CATALOG MUMBER	LIGHTING APPLICATION			
	ATAG	GMA							
LAMP SELECTION AND SPACING GUIDE									

Lamp data is based on manufacturers published information recalculated at approximately 12 volts.

		_							
2,555	33	000,8	4.2	Z1-4	SET6 NON3X	ЗЕАТ			
2,450	97	2,000	8.5	4-15	9729	XSAT			
2,300	23	000'6	0.4	4-12	8276	ASAT			
2,400	٩٤	000,61	7.2	Z1-4	VENON 9731	ТИЭЭЭА			
2,200	8	20,000	1.2	6-12	7276	ТИЭЭЭА			
(TEMP'K) COLOR APPROX.	APPROX. LIGHT (LUMEN)	RATED LIFE (HOURES)	CONSUMED	SPACING SPACING (INCHES)	OOTATAO ABAMUN	LIGHTING APPLICATION			
	ATAG	GMA							
LAMP SELECTION AND SPACING GUIDE									

INSTALLATION AND SAFETY INSTRUCTIONS

FOR YOUR SAFETY

HC-128


WARNING: Be sure the electricity to the system you are working on is turned off; either the fuse removed or the circuit breaker set at off. PLEASE KEEP AWAY FROM COMBUSTIBLE MATERIALS.

(USE ONLY WITH AMBIANCE 105° CABLE)

TO INSTALL 9428 SOCKET

CAUTION:Do not remove reflectors, heat from lamps will damage cable.

- A. Determine socket location and spacing, minimum 4" center to center.
- **B**. Install bulbs (not included), 5 watt maximum.
- **C.** Press socket straight down into track and cable until socket snaps into place.
- D. Center of socket must not be closer than 1 1/2" to closed ends (wall surfaces and partitions).



WARNING: Use of other manufacturers components will void warranty, U.L. listing and create a potential safety hazard.

INSTALLATION AND SAFETY INSTRUCTIONS

FOR YOUR SAFETY

HC-128


WARNING: Be sure the electricity to the system you are working on is turned off; either the fuse removed or the circuit breaker set at off. PLEASE KEEP AWAY FROM COMBUSTIBLE MATERIALS.

(USE ONLY WITH AMBIANCE 105° CABLE)

TO INSTALL 9428 SOCKET

CAUTION:Do not remove reflectors, heat from lamps will damage cable.

- A. Determine socket location and spacing, minimum 4" center to center
- **B**. Install bulbs (not included), 5 watt maximum.
- **C.** Press socket straight down into track and cable until socket snaps into place.
- D. Center of socket must not be closer than 1 1/2" to closed ends (wall surfaces and partitions).



WARNING: Use of other manufacturers components will void warranty, U.L. listing and create a potential safety hazard.