


Instrucciones De Montaje Para

L9615

(E) 2/08




READ ALL INSTRUCTIONS BEFORE ASSEMBLING LAMP

Carefully unpack lamp parts onto carpeted surface or blanket and identify all parts.

1. Grasp Cord that exits from Base and pull carefully until any excess Cord in between parts is removed.
2. Thread Center Body into Base and turn to tighten.
3. Place Socket Assembly on Center Body. Turn to tighten. Then set lamp upright on Base.
4. Place Harp to fit into Yoke by squeezing the bottom of Harp.
5. Install a Type A, 150 Watt Max. 3-Way Medium base bulb (not included) into socket as noted on relamping label at socket area.
6. Unscrew Finial from Harp and set aside. Place Lamp Shade over screw thread of Harp and tighten Finial back in place.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit contact a qualified electrician. Never use with a extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.



**MURRAY
FEISS**

Generation Brands™