



IMPORTANT
TURN OFF THE POWER AT THE MAIN FUSE
OR CIRCUIT BREAKER BOX
BEFORE STARTING INSTALLATION

Carefully unpack and identify all parts before assembly. Bulb is not included.

1. Remove main frame from top cover by unscrewing cap nuts and rubber washer. Set them aside.
2. Install finial by screwing onto bottom of main frame.
3. Install light bulb (not included). See relamping label located at socket area for type and maximum allowed wattage.
4. Install back the main frame onto top cover by fastening with rubber washer and cap nuts.
5. Follow enclosed "Standard Outdoor Mounting plate Installation Instructions" for electrical and fixture installation onto wall outlet box.