



**IMPORTANT:**  
**TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION.**

**Carefully unpack and identify all parts before assembly. Bulbs are not included.**

1. Screw center pipe onto top of socket assembly while removing any slack in wires in between parts.
2. Install arms:
  - A. Install upper section of arms onto studs, which are located at top section of center pipe, by tightening set screw. Use enclosed hex key to tighten.
  - B. Install lower section of arms onto pan by fastening with machine screws.
3. Carefully thread fixture wire and ground wire through fixture loop. Screw fixture loop onto top threaded pipe until secure.
4. Install a hex nut onto one end of long threaded pipe leaving about 1/2" (13 mm) thread exposed. Screw same end of threaded pipe into coupler. Tighten hex nut.
5. Follow enclosed **"Chain Suspended Fixture Installation Instructions"** for electrical and fixture installation onto ceiling outlet box.
6. Slip glass shade up till it checks into bottom of pan. Then lock into position by fastening with flat washer and hex nut. Do not over tighten.
7. Install finial by fastening onto bottom of fixture.
8. Install light bulb (not included). See label located at socket area for type and maximum allowed wattage.
9. Install two glass plates onto top of socket assembly by placing holes in plates through four screw studs and securing with four ball cap nuts. Do not over tighten.