


# Replacement Parts For

# 10160


3/2012




111671 Finial




111672 Shade



101610 Harp



103113 Switch Knob



Qty.	Part #	Description
	111671	Finial
	111672	Shade
	101610	Harp
	103113	Switch Knob

# FEISS®

EST. 1955