


Assembly Instructions

ITEM NO.: 31634



- 1. Thread the LOOP (A) onto the NIPPLE (B). Until tighten!
- 2. Put down the SMALL FRAME (F) onto the fixture! See the FIGURE 1 FIGURE 2 & FIGURE 3. Please pay more attention to do not scratch the finish.
- 3. Unfold the arms to the correct place to match the FRAME (F) & FRAME (J).
- 4. Thread the NIPPLE (I) onto COUPLEN (H). Until tighten!
- 5. Place the SMALL FRAME (F) & BIG FRAME (J) onto the fixture careful. Make sure all of the NIPPLE (I) hade insert the tubings on the FRAME.
- 6. Place the COVER (K) onto the FRAME. Then secured by the BALL NUT (L).
- 7. Measure the height from hanging fixture to your ceiling. Cut the excess chain and wire to fit the height.
- 8. Follow the wattage label on the glass hold and install correct wattage and type bulb (no provide) onto the socket.
- 9. For mounting and wiring step please follow the mounting instruction sheet enclosed.



Assembly Instructions

ITEM NO.: 31633/31634







PICTURE 1 PICTURE 2 PICTURE 3









PICTURE 4 PICTURE 5 PICTURE 6 PICTURE 7

STEP-BY-STEP ASSEMBLY GUIDE

- 1. CAREFULLY REMOVE FIXTURE OUT OF THE BOX.(PICTURE 1)
- 2. THREAD THE LOOP ONTO THE NIPPLE ON THE FIXTURE.
- 3. PUT THE BOTTOM FRAME ON TOP OF A PIECE OF CLOTH OR CARPET AND AVOID ANY SCRATCHES ON THE FIXTURES.(PICTURE 2)
- 4. SPREAD OUT AND ADJUST ARMS EVENLY ON THE FIXTURE.(PICTURE 3)
- 5. TREAD THE NIPPLE ONTO THE BOTTOM OF EACH ARM AS SHOWN.(PICTURE 4)
- 6. CAREFULLY INSERT THE NIPPLE INTO EACH TUBE ON THE FRAME.(PICTURE 5)
- 7. SECURE NIPPLE AND FRAME WITH BOTTOM CAPAND BALL NUT AS SHOWN.(PICTURE 6)
- 8. FIXTURE ASSEMBLY IS COMPLETED.(PICTURE 7)