

## **Installation Instruction**

For Floor Lamp ITEM #8478-57

## WARNING

- \* Risk of shock, do not plug the unit before assembly.
- \* Do not exceed the maximum wattage rating.

## FIXTURE ASSEMBLY

- 1. Carefully remove the fixture from the carton and lay it down over a clean soft surface (blanket or rug) to prevent damage to the finish.
- 2. Attach center part (H) to lamp base (I) and turn clockwise until firmly tightened.
- 3. Connecting the center part (G) to part (H) and turn clockwise until firmly tightened.
- 4. Carefully pull the wire cord through the bottom of base (I) till part (D) can be screwed onto part (G). Please pay attention not to cause wire cord damage pulling.
- 5. Install the lamp body (D) to center part (G) and turn clockwise to tighten.
- 6. Install a 7W light bulb and attach the glass shade (F) to the center of the lamp body (D) using the screws (E).
- 7. Squeeze the harp (C) together and insert into the harp holder (D).
- 8. Install a 150W light bulb, place shade (B) on top of harp and secure with finial (A).

## **IMPORTANT SAFETY INSTRUCTIONS**

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

Livex Lighting