ASSEMBLY AND INSTALLATION INSTRUCTIONS

AV-CHU015

WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: • Before installing, consult local electrical codes for wiring and grounding requirements.

Supplied with 15 feet steel cord for hanging safety assurance.
The way to install depends on your house structure.

 Please read the instruction carefully before you install this fixture. If you are not familiar with installations, please

consult a qualified electrician.

1. Attach nipple(-a) to the mounting strap, then secure it with a washer and hex nut.

2. Attach the mounting strap to the outlet box by using two mounting screws.

NOTE: Apply drywall screws to strengthen the installation of the mounting strap onto the ceiling if in need.

3. Adjust the arms of the fixture according to the drawing of the package. Then screw nipple(-b) into the coupling and secure it with a hex nut. Attach the notched cap with the open side facing down and the font to the fixture by inserting nipple(-b) and secure them with a hex nut and the loop. (Note: Slots in notched cap must locate in position between arms.)

Important:

a. The arms of each tier should be positioned with equal distances between them.

b. The arms should be fixed securely.

4. Choose the length of the chain you need, then weave the fixture wire and the fixture grounding wire through the chain. Then connect one end of the chain with the loop by using the loop lock.

5. Secure the top loop to nipple(-a).

6. Thread the fixture wire and fixture grounding wire through the collar, canopy, top loop, nipple(-a) and mounting strap.

7. Connect the other end of the chain link with the top loop by using the loop lock.

8. Pull out the outlet wires and the house grounding wire from the outlet box. Make wire connections using the wire nuts:

---The smooth wire (marked) from the fixture to the black wire from the power source.

---The ridged wire (unmarked) from the fixture to the white wire from the power source.

---Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut.

Carefully tuck the wires back into the outlet box.

- 9. Attach the canopy to the mounting strap by inserting the top loop, then secure it with the collar.
- 10. Secure the finial onto nipple(-c).
- 11. Attach the glass shades onto the glass holders, then secure them with the socket rings.

Note: All glass shades of each tier should be on the same horizontal level.

- 12. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
- 13. Turn on the power at the main fuse or circuit breaker box.

