ASSEMBLY AND INSTALLATION INSTRUCTIONS

BE-PDD430

> **WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.**

NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
2. READ AND SAVE THESE INSTRUCTIONS.

1. Attach nipple(-a) to the mounting strap, then secure it with a washer and hex nut.
2. Attach the mounting strap to the outlet box by using two mounting screws.
3. Rod connections:
   a. Thread the fixture wire from the fixture through rod(-d). Secure rod(-d) to the fixture with the nipple.
   b. Thread the fixture wire from rod(-d) through rod(-c). Secure rod(-c) to rod(-d) with the nipple.
   c. Thread the fixture wire from rod(-c) through rod(-b). Secure rod(-b) to rod(-c) with the nipple.
   d. Thread the fixture wire from rod(-b) through rod(-a). Secure rod(-a) to rod(-b) with the nipple.
   e. Thread the fixture wire from rod(-a) through the loop. Secure the loop to rod(-a) with the nipple.
   Rods are available in 9", 12", 18" and 24" lengths, choose a desired installation height using the rods.
4. Choose the length of the chain that you need, then weave the fixture wire and the fixture grounding wire through the chain. Then connect one end link of the chain with the loop by using the loop lock.
5. Secure the top loop to nipple(-a) tightly.
6. Thread the fixture wire and fixture grounding wire through the collar, canopy, top loop, nipple(-a) and mounting strap.
7. Connect the link on the other end of the chain with the top loop by using the loop lock.
8. Pull out the outlet wires and the house grounding wire from the outlet box. Make wire connections using the wire nuts:
   ---The smooth wire (marked) from the fixture to the black wire from the power source.
   ---The ridged wire (unmarked) from the fixture to the white wire from the power source.
   ---Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut.
   Carefully tuck the wires back into the outlet box.
9. Attach the canopy to the mounting strap by inserting the top loop, then secure it with the collar.
10. Attach the glass shades to the glass holders, then secure them with the socket rings.
11. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
12. Turn on the power at the main fuse or circuit breaker box.

Outlet Box
House Grounding Wire
Wire Nut
Hex Nut
Washer
Mounting Strap
Green Grounding Screw
Mounting Screw
Nipple(-a)
Canopy
Top Loop
Collar
Loop Lock
Fixture Grounding Wire
Chain
Loop Lock
Fixture Wire
Loop
Nipple
Rod(-a)
Nipple
Rod(-b)
Nipple
Rod(-c)
Nipple
Rod(-d)
Nipple
Fixture
Glass Holder
Glass Shade
Socket Ring
Bulb Type A Max.100W
(not included)

vaxcel

090919