

ASSEMBLY AND INSTALLATION INSTRUCTIONS

CA-CHU008

WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements. 2. READ AND SAVE THIS INSTRUCTION.

1. Attach nipple(-a) to the mounting strap, then secure it with a washer and hex nut.
2. Attach the mounting strap to the outlet box by using two mounting screws.
3. Secure the top loop to nipple(-a).

4. Adjust the arms of the fixture according to the drawing of the package.

Important: The arms of each tier should be positioned with equal distances between them.

5. Attach the notched cap to the fixture by inserting nipple(-b).
Note: The arms should be fixed securely by attaching the notched cap.
6. Attach the font, the metal pad and the tube to the fixture by inserting nipple(-b), then secure them with the loop.

7. Choose the length of the chain you need, then weave the fixture wire and the fixture grounding wire through the chain, collar and canopy.

8. Connect one end of the chain with the loop by using a loop lock.
9. Connect the other end of the chain with the top loop by using another loop lock.

10. Thread the fixture wire and fixture grounding wire through the top loop, nipple(-a) and mounting strap.
11. Pull out the outlet wires and the house grounding wire from the outlet box. Make wire connections using the wire nuts:

- The smooth wire (marked) from the fixture to the black wire from the power source.
- The ridged wire (unmarked) from the fixture to the white wire from the power source.
- Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut.

Carefully tuck the wires back into the outlet box.

12. Attach the canopy to the mounting strap by inserting the top loop, then secure it with the collar.
13. Attach the nipple(-c) to the coupling, secure it with a washer and a hex nut. Then attach the cover to the fixture by inserting nipple(-c), and secure it with the finial.
14. Attach the glass shades to the glass holders, and secure them with the socket rings.
15. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
16. Turn on the power at the main fuse or circuit breaker box.

