

# ASSEMBLY AND INSTALLATION INSTRUCTIONS

CA-PDD380

**WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.**

**NOTE:** 1. Before installing, consult local electrical codes for wiring and grounding requirements.  
2. READ AND SAVE THIS INSTRUCTION.

1. Attach the nipple(-a) to the mounting strap, then secure it with a washer and a hex nut.
2. Attach the mounting strap to the outlet box by using two mounting screws.
3. Secure the finial(-b) to the nipple(-b) tightly.
4. Choose the length of the chains you need, then weave the fixture wire and the fixture grounding wire through one of the chains, top loop and canopy.
5. Connect one ends of the chains with the loops by using two loop locks.
6. Connect the other ends of the chains with the top loops by using another two loop locks.
7. Pull out the outlet wires and house grounding wire from the outlet box. Make wire connections using the wire nuts:

- The smooth wire (marked) from the fixture to the black wire from the power source.
- The ridged wire (unmarked) from the fixture to the white wire from the power source.
- Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut.

Carefully tuck the wires back into the outlet box.

8. Attach the canopy to the mounting strap by inserting the nipple(-a), then secure it with the finial(-a).
9. Screw the nipple(-c) to the coupling, secure it with a washer and a hex nut. Attach the cover to the fixture by inserting the nipple(-c) and secure it with the finial(-c).
10. Attach the glass shades to the glass holders, then secure them with the socket rings.
11. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
12. Turn on the power at the main fuse or circuit breaker box.

