



VOYAGER

User's Manual

change
changer
cambiare

Watch Alarm Timer



press  **1** sec



autom. after 60 sec.



3V-Lithium Battery
CR 1225

20



setting watch
mise à l'heure
poser la hora



change
changer
cambiar



12h / 24h



setting alarm
heure de réveil
programador de alarma




switch off alarm or timer
éteindre le réveil
apagar alarma




setting timer
utilisation du minuteur
programar el minuterio



C= continuous pressure min. 2 sec.
pression continue min 2sec
presión continua 2sec



deactivate alarm
désactiver le réveil
desactivar alarma



after
10 sec
(End)

