

# Downrod Coupler INstallatin Instructions

\*To assure success of this installation be sure to read the instrucitons and review the diagrams thoroughly beofre beginning. Follow the instructions that are applicable for you.

\*NOTE: The important safeguards and instructions apprearing in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors that cannot be built ino any product. These factors must be supplied by the person(s) caring for and operat-ing the unit.

Your downrod coupler is designed to allow you to use a combination of two downrods when the length of an individual downrod is not sufficient. To use your coupler you will need to have available two downrods of 1/2" pipe with at least one end of each downrod threaded to 14 threads per inch. You can order additional Monte Carlo downrods from the store where you purchased the coupler.

