


## ITEM # 120286 DIGITAL SPRING DYNAMOMETER

If the unit is not turning on, even after replacing the batteries, it may be due to the batteries not making a connection. Follow the steps below to ensure a correct connection to the batteries.

Open the battery cover on the back of the Item.



Locate the spring which is underneath 2 plastic "sides" and use an open paperclip to gently pull the spring forward in front of the plastic sides. Do the same thing for both side slots where batteries go. The batteries will now make a connection.