

Jetrunner Ride-On-Toy User Manual Guide for CT-558, 568, 658, 855, 885

Charging Instructions:

1. The vehicle has been fully charged before released from the factory. Nevertheless, please charge for 4-8 hours before your first use to ensure sufficient electric power.
2. Charge immediately after each ride to ensure sufficient power at any time, thereby extending battery life.
3. When the vehicle runs at a rate slower than the normal speed, charge immediately. Please charge the battery monthly if it has not been used for 30 days or more.
4. For charging method, connect red and battery plugs. (Disconnect if battery and main wire lugs are linked, then connect the charger and battery plugs.) Plug the other end of charger into ordinary household receptacle for about 10 hours.
5. During the charging process, the charging set will appear slightly heated, otherwise either the charging set, battery, or the fuse has been burned out.
6. Any continued charging process must not exceed 16 hours.

User Guide:

1. Please read the manual thoroughly before attempt to operate the vehicle.
2. The vehicle is only designed for driving on smooth or cement surface. NEVER drive on sandy, beach, soft soil, mud, uneven surface or where water gathers.
3. This is an electric driven vehicle; all electric components shall be always kept away from the moist. NEVER wash the body with water.
4. Never shift the gear from high to low or vice versa in the forward or reverse movement during driving.
5. Follow the user manual for the vehicle weight capacity. NEVER allow more than 2 rider and over the weight capacity.
CT-558, 658, 855, 885 – 110 lbs
CT-568 – 55 lbs