

Use this belt to secure TVs, monitors, and audio/visual equipment to Peerless Jumbo Carts and mounting brackets.

Because the size and shape of TVs, monitors, and audio/visual equipment varies from model to model it is up to the installer to determine the best method of belting the equipment to the TV stand, cart or bracket.

Ratchet Tie-Down Belt Model: ACC666


Peerless Industries, Inc.
1980 Hawthorne Avenue
Melrose Park, IL 60160

For customer service call
1-800-729-0307 or
708-865-8870

Visit the Peerless web site at www.peerlessindustries.com.

1

Wrap belt around TV or monitor and mounting surface. Insert end of belt through ratchet reel and pull until ALL slack is out of belt.




2

Pump ratchet handle to tighten belt. For secure hold, ratchet reel must have at least two layers of belt around it.

Note: Too many layers of belt around ratchet reel will cause it to jam. To avoid this problem be sure to remove ALL slack from belt before pumping ratchet handle.

After belt is tight, close ratchet handle.



3

To release, compress release bar and open ratchet handle 180°.

