


Oasis Mailbox, Drop Box (Models 5100, 5103 & 6200)

Mounting and Use Instructions

Attaching the flag (models 5100 and 6200 only)

Your new mailbox comes with an outgoing flag. Attach the flag to the mailbox with the two nuts as shown below. If you plan to install your mailbox in a masonry pilaster, the flag can be left off the mailbox and mounted on the outside of the pilaster with masonry hardware (not included).



Using your new box

INCOMING DELIVERIES - Your Oasis Mailbox or Drop Box is equipped with a hopper style door design for incoming mail. This design is often used in high security applications, such as bank depositories, book drops and mail collection boxes. The door allows for the secure delivery of many small to medium sized parcels.

KEYS - Your new box comes with two keys. The keys allow access to the storage compartment. To retrieve incoming deliveries, simply open the access door at the bottom of the box. IT IS IMPORTANT TO NOTE THAT IT IS NOT THE RESPONSIBILITY OF MAIL CARRIERS TO OPEN MAILBOXES THAT ARE LOCKED, ACCEPT KEYS FOR THIS PURPOSE, OR LOCK MAILBOXES AFTER DELIVERY OF THE MAIL.

OUTGOING MAIL (models 5100 and 6200 only) - If you want to leave mail for your carrier to pick up, place the mail under the outgoing mail clip and raise the red mail flag. Upon your carrier's next delivery, he or she will retrieve your outgoing mail and lower the flag.

