



G98040

MOON & STARS MEDIA CAROUSEL


PARTS LIST



A x1



B x2



D x1



K x6



L x6




H x4




I x4




J x4




E x2



F x2




G x2




ASSEMBLY DIAGRAM


1.




2.




3.




4.





5.



6.



7.



© 2003 Guidecraft USA
Englewood, NJ 07631
(800)524-3555
www.Guidecraft.com

For ages 3 and up.
Adult assembly required.

Assembly Note : To ease assembly, do not fully tighten screws during assembly process. After unit is fully assembled go back and tighten all screws.

▲ WARNING

Small parts and sharp points may be present prior to assembly.