INSTRUCTIONS: Display Fixture Model: **DL-007**

IMPORTANT SAFETY INSTRUCTIONS Lighted lamp is HOT:

WARNING - To reduce the risk of FIRE, ELECTRIC SHOCK, EXPOSURE TO EXCESSIVE UV RADIATION, and OR INJURY TO PERSONS:

- 1. Turn off/unplug and allow cooling before replacing bulb (lamp).
- 2. Bulb (lamp) gets HOT quickly! Only contact switch/plug when turning on.
- 3. Do not touch hot lens, or guard.
- 4. Do not remain in light if skin feels warm.
- 5. Do not look directly at lighted lamp.
- 6. Keep lamp away from materials that may burn.
- 7. Use only with a 50-watt or smaller bulb (lamp).
- 8. Do not touch the bulb (lamp) at any time. Use a soft cloth. Oil from skin may damage bulb (lamp).
- 9. Do not operate the luminaire with a missing guard.

SAVE THESE INSTRUCTIONS

Installing Lamp:

- 1. Use a 12V MR16 lamp 50watt maximum (purchase separately).
- 2. Align lamp pins with socket holes and gently press in.
- 3. Place Clear glass lens over lamp and secure with retaining ring.

Installing Clamp:

- 1. Installs on a firm flat surface, such as wood, particleboard, cubicle partition etc. Standard clamp accommodates surfaces 1/2" to 2 1/2" wide.
- 2. Use the angle adjustment knob on the side to change the angle.
- 3. Adjust the height by sliding the telescoping rod.

Accessories:

- 1. Supplied with standard clamp that opens to $2\frac{1}{2}$ wide.
- 2. An optional "DLC-4" clamp opens to 4".
- 3. An optional DLC-P clamp works on 2 1/2" pipe
- 4. Fixture supplied with clear glass lens. Maybe substituted with various accessory lenses consult catalog for compatibility.



615 South Street, Garden City, NY 11530 Tel: (516) 515-5000 Fax: (516) 516-5050