## INSTRUCTIONS PERTAINING TO A RISK OF FIRE, OR INJURY

Lighted lamp is HOT!

WARNING- To reduce the risk of FIRE OR INJURY: Turn off all power and allow to cool before replacing lamp. Lamp gets HOT quickly! Contact only switch/plug when

turning on.

Do not touch lens, guard, or enclosure.

Keep away from materials that may burn.

Do not touch the lamp at any time. Use a soft cloth. Oil from skin may damage lamp.

Do not operate the luminaire with a missing lens or damaged shield.

Save these instructions.

**Overview:** Fixtures are designed for use with all WAC quick connect adapters. They may also be used on other manufacturers brand of quick connect (consult factory for compatibility).

This fixture may be mounted to mono rail, monopoints, or standard track, by coupling to a female quick connect adapter.

The fixture is compatible with various metal and glass shade choices (see below).

## Installing lamp & Shade:

1. Place the lamp inside the shade so the two pins protrude through the back. Insert the lamp into the fixture by aligning the pins with the socket holes, and gently pushing until lamp seats.

Use an MR16-G (glass covered)

lamp 50 watts maximum (12 or 24 volt depending on power supply).


 Attach the shade by twisting and pushing in one continuous motion over the spring band. Note: May be used with 50W Xenon bi-pin lamp.


## Installing the quick connect:

- 1. Insert the post of the quick connect into the quick connect adapter.
- 2. Thread the top half of the conical section until it seats with the adapter.
- 3. Adjust fixture position, use caution not to loosen the conical section.

## Accessories:

Accepts glass or metal Shades from the G100 series.







 615 South Street, Garden City, NY 11530

 W·A·C
 LIGHTING

 Tel: (516) 515-5000
 Fax: (516) 516-5050

 168 Brea Canyon Road, City of Industry, CA 91789

 Tel: (909) 468-1848
 Fax: (909) 468-9958
 09//01/06

 12/13/02 REV 1