1.0



#### **PENDANTS**


### **GENERAL PRODUCT INFORMATION:**



This product is suitable for damp locations.

This product can be dimmed with a standard incandescent dimmer.

## **Install the Lamp**



**CAUTION:** To reduce the risk of a burn or electric shock during relamping, disconnect the power to the fixture.

Use **MAX** 120 Volt, 35 Watt Incandescent PAR20 lamp.




1 Screw the lamp base completely into the socket.




**Note:** If it is difficult to reach the socket for lamp installation or replacement, follow the optional lamp installation to disassemble the fixture.

# **Optional Lamp Installation**



1 Carefully remove the shade by unscrewing the three mounting screws on top of the fixture.



**CAUTION:** To reduce the risk of a burn or electric shock during relamping, disconnect the power to the fixture.

Use **MAX** 120 Volt, 35 Watt Incandescent PAR20 lamp.



- 2 Screw the lamp base completely into the socket.
- 3 Reinstall the shade by reversing figure 2A.

### IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electrical shock, exposure to excessive UV radiation, or injury to person:

- Use this fixture indoors only.
- Do not look directly at the lighted lamp.
- Do not remain in light if skin feels warm.
- Risk of fire: Use only the type of lamp and maximum wattage indicated in this instruction manual.
- Never cover the lamp with anything. Never place flammable material close to your fixture.
- Never turn the fixture on and off by connecting and disconnecting the lamp.
- Do not touch the lamp while the fixture is on. This surface may be HOT.

## **SAVE THESE INSTRUCTIONS!**



7400 Linder Ave, Skokie, IL 60077 847.410.4400

### www.techlighting.com

© 2008 Tech Lighting, L.L.C. All rights reserved. The "Tech Lighting" graphic is a registered trademark of Tech Lighting, L.L.C. Tech Lighting reserves the right to change specifications for product improvements without notification.

A Generation Brands Company