INSTALLATION INSTRUCTIONS FOR 1143 1144 1145 1146 1148 For Wall Mount Fixture

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.

MOUNTING THE FIXTURE

Installation (see fig.1)

- 1.Disconnect power at main electrical panel before installation.
- 2.Mount the back plate(B) to the wall with the plastic anchors(A) ,the wood screw (D) and the two box screws (C). The side of the back plate marked "GND" must face out.
- 3.Guide fixture wires through hole in center of back plate.
- 4.Follow wiring instructions carefully (see fig.2)
- 5. Place the plate(E) over the back plate so that the back plate sockets protrude through the plate(E) holes and lock it securely with cups (F) until sung.
- 6.Install the light bulbs in accordance with the fixture's specifications. **DO NOT EXCEED THE MAXIMUM WATTAGE RATING!**

Wiring (see fig.2)

- 1.Connect the electrical wires as follows. Connect the Black wire from the fixture to the black house (hot) Wire. Connect the white wire from the fixture to the white (neutral) house wire. Make sure all wire nuts are secured. You may wrap the connections with electrical tape. If your outlet box has a ground wire (green or bare copper) connect fixture's ground wire to it. Otherwise attach the bare copper fixture wire to the green ground screw on the circular strap.
- 2. Tuck the wire connections neatly into the wall junction box.




Fig.2					
FIXTURE WIRES Black or Smooth	HOUSE WIRES Black (Hot)	FIXTURE WIRES White or Ribbed	HOUSE WIRES White (Neutra	FIXTURE WIRES Bare Copper (Ground) Ho WI	DUSE IRES reen or Copper(Ground)

