## ASSEMBLING & INSTALLATION INSTRUCTIONS FOR PRODUCT# 4190 For Ceiling Mount Fixtures

## WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER. **MOUNTING THE FIXTURE (Fig.1)** Fig.1 Shut off the power at the circuit breaker box. Remove old fixture and all hardware from Junction Box. Supply 2. Carefully unpack your new fixture and lay out all the parts Ground wire Supply wire on a clear area. Take care not to lose any small parts necessary for installation. Junction Box 3. Thread the two Mounting screw (A) about 1/4" into the Mounting Screw (A) pre-drilled holes in the Mounting plate spaced the same distance apart as the holes in the canopy(B). Mounting plate 4. Attach the Mounting plate to the Junction Box with the two Ground Screw Junction Box Screws as shown. The side of the Mounting Box screw plate marked "GND" must face out. Wire nut 5. While holding the canopy assembly towards the ceiling, Fixture wire connect the electrical wires as Shown in Fig.2, making Fixture Ground wire sure that all wire nuts are secured. You may have to wrap - B the connections with electrical tape. If your outlet has a ground wire (green or bare copper), connect the fixture C ground wire to it. Otherwise connect fixture's ground wire directly to the Mounting plate with the green screw provided. After wires are connected, tuck them carefully inside the Junction Box. **6.** Raise the canopy assembly onto the junction box, aligning screws on mounting plate with mounting holes in canopy and lock it securely with the ball nut (C). 7. Install the light bulbs in accordance with the fixture's specifications. **NOTE: DO NOT EXCEED** THE D **SPECIFIED WATTAGE.** F 8. Raise the cover (D), glass shade (E) and cover (F) to the bottom nipple of the canopy (B), using the hex nut (G) by turning it clockwise until tight and lock it with the finial (H). F G Н Your installation is now complete. Return power to the junction box and test the fixture. Fig.2 MIN 90°C SUPPLY CONDUCTORS FIXTURE FIXTURE FIXTURE WIRES WIRES WIRES Black or White or Bare Smooth Copper Ribbed (Ground) HOUSE HOUSE HOUSE

WIRES

Green or

Bare Copper (Ground)

WIRES

White

(Neutral)

WIRES

Black

(Hot)

