

Sharp R830 Convection Microwave



General Specifications

- 0.9 Cu. Ft Convection
- 900 watts MWO output power
- 1700 watts Heat Output power
- Dual Element Convection (Upper and Lower)
- Alphanumeric LED Digital Control

Features

- Convection Cooking
- 12-3/4" Carousel® Turntable System
- 10 Cooking Power Levels
- Combination Microwave & Convection Cooking
- 6 Instant Action Options (e.g. POPCORN)
- Defrost by Weight & Time
- 6 Auto Roast Options
- 7 Auto Cook Settings
- 3 Roast Settings
- 4 Stage Cooking
- Digital Clock & Kitchen Timer
- + 30 Seconds Key
- Child Lock Feature
- Demo Mode
- Audible Signal Elimination
- Colors/Finish: Stainless Steel or Black



R830 Control Panel



| AUTO ROAST | AUTO COOK | AUTO DEFROST |
|---------------------------|------------------------|-------------------|
| 1. Roast Beef | 1. Frozen Pizza | 1. Steak & Chops |
| 2. Fried Chicken | 2. Reheat Pizza | 2. Poultry |
| 3. Roast Chicken | 3. Fries | 3. Ground Beef |
| 4. Roast Pork | 4. Frozen Pasta | 4. Chicken Pieces |
| 5. Grilled Steak & Chops | 5. Fish Sticks & Cakes | 5. Roasts |
| 6. Grilled Chicken Pieces | 6. Finger Foods | |
| | 7. Hard Vegetables | |

INSTANT ACTION CHART

| FOOD | AMOUNT | PROCEDURE |
|-------------------|------------------------|---|
| DINNER PLATE | 1 servings | Place on the low rack and cover with plastic wrap. Touch DINNER PLATE once. Let stand covered 2 minutes. |
| POPCORN | 1 package | Use only popcorn packaged for microwave oven use. Try several brands to decide which you like the best. Do not try to pop un-popped kernels. Use low rack and microwave safe plate. |
| | 2.7 - 3.3 oz (Regular) | Touch POPCORN once for regular size bags. |
| | 1.1 - 1.6 oz (Snack) | Touch POPCORN twice for snack size bags. |
| VEGETABLES (Soft) | 1 - 4 cups | Cover with a lid or plastic wrap. Let stand 1 to 5 minutes then stir. Touch VEGETABLES once for 1 cup. Touch VEGETABLES twice for 2 cups. Touch VEGETABLES three times for 3 cups. Touch VEGETABLES 4 times for 4 cups. |
| FROZEN VEGETABLES | 1 - 4 cups | Cover with a lid or plastic wrap. Let stand 1 to 5 minutes then stir. Touch FROZEN VEGETABLES once for 1 cup. Touch FROZEN VEGETABLES twice for 2 cups. Touch FROZEN VEGETABLES three times for 3 cups. Touch FROZEN VEGETABLES 4 times for 4 cups. |
| POTATOES | 1 - 4 potatoes | Pierce each potato twice on each side. Let potatoes stand covered in foil 3 to 10 minutes. Touch POTATOES once for 1 potato. Touch POTATOES twice for 2 potatoes. Touch POTATOES three times for 3 potatoes. Touch POTATOES four times for 4 potatoes. |
| FROZEN ENTRÉE | 4 size options | Do not cover while cooking, always use the low rack. Touch FROZEN ENTRÉE once for 6 to 8 ounces. Touch FROZEN ENTRÉE twice for 9 to 11 ounces. Touch FROZEN ENTRÉE three times for 12 to 14 ounces. Touch FROZEN ENTRÉE four times for 15 to 17 ounces. Let stand covered 1 to 5 minutes then stir. |