



Replacement of Optima Plus RESS Module to G2 Module EBV-146-A

1 **Removal of Optima Plus RESS Module**

A. With water supply and pressure turned off, remove Locking Ring by turning counterclockwise.

B. Remove Outer Cover.

C. Remove RESS Module.

2 **G2 Module Preparation**

A. Remove tape and magnet entirely from Module. Start up Mode will activate (sensor flashes continuously).

B. It is normal to find water inside bottom hole.

3 **Installation of G2 Module**

A. Seat G2 Module onto Diaphragm Assembly.

B. Seat Outer Cover over G2 Module.

C. Install and tighten Locking Ring securely.



any
 questions
?

The information contained in this document is subject to change without notice.

- We recommend that you review our Regal PRO OPTIMA *Plus* Installation Instructions and Maintenance Guides for complete instructions including Rough-in Dimensions, Specifications, Troubleshooting Guide, and Replacement Parts.
- Call our Installation Engineers for additional information at 1-888-SLOAN-14 or fax them at 1-800-737-3061.