


ASSEMBLY INSTRUCTIONS: BASIX SERIES 3 STATION WORKCENTER (1400)



INSTRUCTIONS

1. Lay the top upside down on a clean, scratch free surface.
2. Screw legs into leg mount.
3. Locate wire basket under top and pull tray to the lower position to store excess cords.
4. Locate wire channel. Peel paper on adhesive back and attach to leg nearest the wall or floor outlet. Place power cord inside channel to prevent dangling cords.
5. When moving this unit, pick it up and carry it. Do not push, pull, or slide the unit.