


## **ASSEMBLY INSTRUCTIONS**

## ITEM#12558



- 1. FASTEN THE ADJUSTABLE TUBE INTO THE SWING ARM ASSEMBLY
- 2. FASTEN THE TUBE WITH SWING ARM ASSEMBLY TOGETHER ONTO BASE, BE CAREFUL NOT TO TWIST POWER CORD, TIGHTEN SECURELY.
- 3. LOOSEN THE ADJUSTING SCREW TO PLACE THE ADJUSTABLE TUBE IN THE DESIRED POSITION, THEN TIGHTEN THE ADJUSTING SCREW.

5.INSTALL THE TYPE "SP" BULB INTO THE SOCKET.(BULB INCLUDED)

## **IMPORTANT SAFETY INSTRUCTIONS**

THIS PORTABLE LAMP HAS A POLARIZED PLUG(ONE BLADE IS WIDER THAN THE OTHER ) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY.IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG.IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED.DO NOT ALTER THE PLUG.