


- Lay (a) on the ground, circle w facing up.
- Insert G and D pieces. Insert D last.

## Note:

Every tab has a groove on one side. Every slot has an indent. The groove and the indent need to align to work correctly.















- Press d down to lock Tension tabs. 0
- Ensure tabs are pressed securely. Ш
- DO NOT lock 🖸 yet.

## Note


2

Pressing tabs together creates Tension Lock. This will require effort. Stand up, and use your weight to press down.

Press tabs almost to the end, as shown below.



Parts Θ Seat TP005KX



- Press down on back piece to lock it into place 🛛.
- Press chair sides together again.
- Securely press seat slots onto tabs Z.







Weight capacity 150 lbs

**KIDS TABLE** 










To level, turn table and press on top firmly.



- Align leg pieces to base mounting points and press the center firmly.
- 2 Press legs to lock firmly all five mounting points.

## Sprout www.sprout-kids.com





sqo.so/kta

see online assembly video & more

- Δ Adult assembly only
- Assemble completely Л before use

Δ Do not climb or stand on table

- For children ages 4-7
- Weight capacity 150 lbs



Θ Back HZ002KX

 $\frown$ 



