Power Jack Om With Ceramic Metal Halide T4

1.9





HEADS-LINE VOLTAGE

GENERAL PRODUCT INFORMATION:



This product is suitable for indoor dry locations only.

This product is intended for use only with Tech Lighting Power Jack & T∼trak[™] systems.

This product is patented (U.S. PAT. 7,172,332).

Installing the CMH T4 Lamp



NOTE: Turn off power to the system before installing, removing, or relamping the fixture.

Remove the front ring from the body by unscrewing it counterclockwise.

NOTE: Use only your fingers and a soft cloth to replace the lamp.



700PJOMT4



Use 120 Volt, 20 Watt Ceramic Metal Halide T4.5 Lamp with 700PJOMT4_2_ Models.

Use 120 Volt, 39 Watt Ceramic Metal Halide T4.5 Lamp with 700PJOMT4_3_ Models.

Use 120 Volt, 70 Watt Ceramic Metal Halide T4.5 Lamp with 700PJOMT4_7_ Models.

2 Handle the new replacement lamp with a soft cloth to prevent the natural oils on the fingertips from collecting on the lamp. This will help extend the life of the lamp.

3 Insert the lamp pins completely into the socket holes.

NOTE: Steps 3 to 5 are required to shield the lamp from possible shattering.



SPECIAL INSTALLATION: Locking the Fixture in Permanent Position (Optional)



- To lock the fixture head in a permanent vertical position, loosen (DO NOT REMOVE) the #6-32 set screw on fixture arm with the provided 1/16 Allen wrench.
- **2** Rotate the fixture head to the desired position.
- 3 Tighten the #6-32 set screw with the 1/16 Allen wrench.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electrical shock, exposure to excessive UV radiation, or injury to person:

- Use this fixture indoors only.
- Do not look directly at the lighted lamp.
- Do not remain in light if skin feels warm.
- Risk of fire: Use only the type of lamp and maximum wattage indicated in this instruction manual.
- Never cover the Ceramic Metal Halide lamp with anything other than a Tech Lighting lens and never place flammable material close to your fixture.
- Never turn the fixture on and off by connecting and disconnecting the CMH lamp.
- Do not touch the fixture shades or lamp shield while the fixture is on. These surfaces may be HOT.
- Relamp fixtures at or before the end of rated life. Beyond rated life, light output diminishes while energy consumption and risk of rupture increases.

CMH Lamp General Information

 A new CMH lamp is a discharge lamp and requires some time to start and come to full brightness after a power interruption.

Two Tips For Prolonging CMH Lamp Life

- First avoid touching the lamp with bare hands during installation. Any contaminant, even the oil from your hands can deteriorate the lamp. A soft cloth can be used to remove any contaminant.
- Second, do not run the lamps continuously operating, turn the lamp off once per week for at least 15 minutes. This will reduce the risk of rupture.

SAVE THESE INSTRUCTIONS!



a brand of **TECH** LIGHTING^{*}

7400 Linder Ave, Skokie, IL 60077 847.410.4400

www.ttraklighting.com

© 2010 Tech Lighting, L.L.C. All rights reserved. The "T~trak"^{see} graphic is a registered trademark of T--trak"^{see}. T~trak^{tec} reserves the right to change specifications for product improvements without notification. A Generation Brands Company