


4 DC

METAL RETRO CHAIR (Yellow Original)

MODEL: 71140



Dimensions:

22.5"(L) x 27"(W) x 35.5"(H)

NEED ASSISTANCE ?

Call 4D CONCEPTS directly for parts or assembly assistance.

Individual stores do not stock parts

Call our Toll-free number 5 days a week except holidays:

Monday through Friday 8.00am to 5.00pm

Pacific Standard Time

1-888-310-4DCO or 1-888-310 4326

IMPORTANT: Before calling please have the model number and the packing code number ready for our customer service representatives.

You will find the model number printed on the carton label and the packing code printed in black ink on the side of the carton.








Model 71140 Packing code

It is important that you retain the model number and the packing code along with the original receipt of purchase for future reference.









Made in China

71140 ASSEMBLY INSTRUCTION

PARTS LIST:




<p>(A) Back Qty: 1</p> 	<p>(B) Seat Qty: 1</p> 	<p>(C) Right Arm frame Qty: 1</p> 	<p>(D) Left Arm frame Qty: 1</p> 
<p>(E) Connecting Tube Qty: 1</p> 	<p>(F) Arm Cover Qty: 2</p> 	<p>(G) Rubber feet Qty: 4</p> 	


HARDWARE LIST:

<p>1. Screw Qty: 4 6 x 10 mm</p> 	<p>2. Bolt Qty: 2 6 x 10 mm</p> 	<p>3. Bolt Qty: 10 6 x 35 mm</p> 	<p>4. Bolt Qty: 2 6 x 48 mm</p> 
<p>5. Washer Qty: 14</p> 	<p>6. Nut Qty: 10</p> 	<p>7. Round top nut Qty: 2</p> 	<p>8. Spanner Qty: 1</p> 

ATTENTION : DO NOT TIGHTEN ALL OF THE NUTS UNTIL THE FINAL STEP IS COMPLETED. IMPORTANT TO FULLY TIGHTEN BEFORE SITTING ON CHAIR.

Step 1

Item	Drawing	Qty
1		4
2		2
5		2







Attach the four rubber feet (G) at the bottom of the arm side frames (C/D) with screws (1) as shown. Insert the rear connecting tube (E) to each of the arm side frames (C/D) as shown.

The fit should be tight, and completely together. If you can't push them completely together, check the open ends of the side frames for burrs or excess powder coat paint.

Clear them out with sandpaper. Secure tube with bolt (2) and washer (5). Assemble as shown.

Step 2


Item	Drawing	Qty
3		6
5		6
6		6






Attach the seat bottom (B) to side frame on both sides with screw (3) on the outside, washer (5) and nut (6) on the inside. Assemble as shown.

ATTENTION : DO NOT TIGHTEN ALL OF THE NUTS UNTIL THE FINAL STEP IS COMPLETED. IMPORTANT TO FULLY TIGHTEN BEFORE SITTING ON CHAIR.

Step 3




Item	Drawing	Qty
3		4
5		4
6		4




Attach the seat back (A) to side frames, on both sides with bolt (3) on the outside, washer (5) and nut (6) on the inside. Assemble as shown.

IMPORTANT:

Exposure to harsh weather conditions may encourage rusting of the steel metal components. Protection from these conditions is recommended.

Step 4



Item	Drawing	Qty
4		2
5		2
7		2

Carefully line up holes in arm cover (F) with holes on chair frames. Using a quick downward push, snap cover over frame. Attach arm holder (F) to each side frame with the bolt (4).

The washer (5) and round top nut (7) should be used underneath the arm cover. Assemble as shown.