


Assembly Manual & User's Guide



Lamborghini Murciéalgo LP 670-4 SV

Item No.: KL-7001 12V



 **WARNING:** Adult assembly required.
Please read this manual carefully before assembly and use.



Lamborghini Murciéalgo LP 670-4 SV is a registered trademark owned and licensed by Lamborghini Artimarcas S.P.A.
Manufactured by Kalee Children's Products Co., Ltd., www.lamborghini.com

Vehicle / Battery Specifications:

Age: 3-7 Years

Maximum Capacity: 25 kgs

Max Speed: about 3.5 km/h

Battery Type: Sealed lead-acid rechargeable, 12 Volt 7Ah

Charging time: Always charge the battery for 8-10 hours before first use and when recharging is needed. Never charge for more than 20 hours.

Power input for Charger: A/C 100-240 Volts

Power output to Battery: DC 14 Volts, 1000MA

WARNING:

1. Use the toy only on flat surfaces, such as sidewalks, driveways or playgrounds. Do not ride the vehicle in dangerous places such as busy streets, roads or highways.
2. Never use near swimming pools or other bodies of water.
3. Never ride the vehicle in muddy or sandy areas. Never ride in hilly areas or on steep slopes. This vehicle was made to operate on dry leveled ground.
4. Never ride in the dark or in dimly lit areas.
5. Clean the vehicle only with a damp cloth and never submerge vehicle in water or spray with water directly from a hose.
6. Only one child should ride this vehicle at a time.
7. Do not exceed the recommended weight limit of 25 kgs.
8. To avoid suffocation of children please destroy all plastic bags after assembly of the vehicle.
9. If vehicle is equipped with a forward / reverse switch, never press this switch while vehicle is in motion. Always stop the vehicle before switching directions.

WARNING:

To reduce the risk of injury, adult supervision is required.

Never use on roadways, near motor vehicles, on or near steep inclines or steps, swimming pools or other bodies of water. Always wear shoes and never allow more than 1 rider.

WARNING:

Contains small parts, sharp points and sharp edges. Adult assembly required.

WARNING:

Choking Hazard! Contains small parts. Not for children under 3 years old!

Caution:

The ride on vehicle is equipped with a built-in thermal circuit breaker. The thermal circuit breaker is a self-resetting safety device which automatically "trips" and shuts down the operation of the vehicle if it is overloaded or the driving conditions are too severe. Once the circuit breaker has tripped it will automatically reset itself after approximately 25 seconds and allow the rider to resume normal operation.

CHARGING CAUTIONS:

- The charger is not a toy. Do not allow children to play with the charger or to recharge the battery.
- Turn the power switch to "OFF" when charging.
- Before the first use, you should charge the battery for 8-10 hours. Do not charge the battery for more than 20 hours to avoid overheating the charger.
- It is normal for the charger to feel warm during charging. If the charger feels very hot, stop charging, unplug the charger and check the battery and charger.
- Use the charger in dry locations only.
- Regularly check the charger, battery and their connectors for excessive wear or damage each time you charge the battery. If damage or excessive wear is detected, do not use the charger or the battery until you have replaced the worn or damaged part.

BATTERY SAFETY WARNING:

- Only use the battery and charger supplied by the manufacturer.
- Do not connect the battery terminals directly together. This will cause the battery to short-circuit.
- Never short-circuit the battery terminals or modify the electrical system. Alterations may cause a fire resulting in serious injuries.
- Do not mix old and new batteries or batteries of different types.
- Remove batteries during long periods of non-use. Always remove batteries from the product. Dispose of batteries safely. Do not dispose of batteries in fires. The batteries may explode or leak.
- If removable, rechargeable batteries are used, they are only to be charged under adult supervision.
- Recharge the battery fully before storage, then charge it every 3 months to extend the life of the battery.



WARNING - Risk of fire. Do not by pass fuse. Replace only with the correct amperage fuse.


Trouble-Shoting:

1. If vehicle fails to move:
 - a) Make sure the battery wires are connected properly.
 - b) Recharge the battery, if necessary.
 - c) Check the fuse and replace if damaged.
2. If vehicle runs slowly:
 - a) Recharge the battery.
3. If the battery can not recharged:
 - a) Battery or charger may be damaged. Replace if necessary.

Part List:


Part No.		Description	Qty
1.		Body with wheels	1 set
2.		M5 Screw	1 pc
3.		M5 Nut	1 pc
4.		TA3.5x12x9 Screw	2 pcs
5.		TA3.5x12x6.5 Screw	3 pcs
6.		Steering wheel	1 pc
7.		Seat	1 pc
8.		Rearview Mirror	1 pair
9.		Spoiler Bracket	1 pair
10.		Spoiler	1 pc
11.		14V 1000mA Charger	1 pc
12.		Screwdriver (not included)	1 pc

How to assemble the vehicle:




Step 1:

- Place the steering wheel(#5) onto the steering wheel column.




Step 2:

- Insert the M5 screw (#2) through the steering wheel column.
- Tighten the M5 Nut(#3) with a screwdriver (Not included).



⚠ WARNING:


Do not change directions while vehicle is in motion.



Note: Please make sure to connect the Red Plug to the Battery Plug first before installing the seat.


Step 3:

- Place the seat onto the body and tighten with a screw(#5).




Step 4:

- Place the Rearview Mirrors onto the windshield respectively.
- Tighten the mirrors with screws(#5).



Step 5

- Place the Left and Right Spoiler Bracket (#9) onto the rear bumper.
- Tighten with screws(#4) correctly.



Step 6

- Place the Spoiler(#10) onto Spoiler Brackets properly.


Operation of the Vehicle:

1. Make sure the battery is fully charged and the motor plug is connected to the battery plug.
2. Locate the direction switch to the right of the steering wheel. Press the direction switch to "F" and press the accelerator pedal, vehicle will move forward. Headlights come on while moving forward.
3. To stop the vehicle remove foot from accelerator pedal. When stopped press the direction switch to "B" then press the accelerator pedal, vehicle will move backward.

NOTE: Do not change directions while vehicle is in motion.


4. Press the button in the center of the steering wheel for horn sound.

Charging the Battery:



- The socket for charging the battery is located near the seat.
- Connect the charger plug into the DC jack, then plug the charger into a household outlet.
- Charge the battery for 8-10 hours. Never charge more than 20 hours.
- When the battery is fully charged, unplug the charger and store it in a cool and dry place.

BOM List:



- | | |
|---|--|
| 1. Remote Control Motor | 19. Rear Light Receptacle (Left and Right) |
| 2. Head Light Receptacle (Left and Right) | 20. Rear Light(Left and Right) |
| 3. Head Light(Left and Right) | 21. Spoiler |
| 4. Front Bumper A | 22. Rear Bumper |
| 5. Front Bumper B | 23. Spoiler Bracket (Left and Right) |
| 6. Balancing Pole | 24. Hub Cap |
| 7. Bonnet/Hood | 25. Rear Wheel |
| 8. Rearview mirror(Left and Right) | 26. Motor Accessories |
| 9. Body | 27. Motor and Gear Box |
| 10. Windscreen | 28. Charger Lid |
| 11. Windshield | 29. Pedal Switch |
| 12. Dashboard | 30. Middle Line Lid |
| 13. Switch Case | 31. Side Bumper |
| 14. Steering Wheel | 32. Adornment of Side Bumper |
| 15. Steering Wheel Column | 33. Front Wheel |
| 16. Seat | 34. Plastic spacer |
| 17. Decoration Lid | 35. Washer |
| 18. Boot Lid/Trunk Lid | 36. Front Axle(Left and Right) |