


IMPORTANT
 TURN OFF POWER AT MAIN FUSE TO CIRCUIT
 BREAKER BOX BEFORE STARTING INSTALLATION

1. Carefully unpack and identify all parts.
2. Remove roof by unfastening screws from roof. Slid top threaded pipe thru top of roof and attach to finial. Secure finial to top of roof by tighten hex nut to top of roof. Make sure not to over tighten.
3. Install light bulb (not included). See relamping label, located near socket, for type and maximum allowed wattage.
4. Secure roof to main frame by reassembling screws to roof.
5. Slip post cup over bottom threaded pipe. Slip washer with ground wire, metal washer and rubber washer over bottom threaded pipe, secure all with hex nut.
6. Electrical installation onto post: If you are replacing an existing fixture, disconnect and remove the old fixture.
 - A) Slip post cup over post. Mark position of holes in post cup on post.
 - B) Remove post cup and expose the supply wiring from above post. Drill 1/8" diameter pilot holes in post at places where marked.
 - C) Make wire connections. (wire connectors not provided). Refer to chart below for correct connections. Wire supply wires to fixture wires accordingly.

Connect Black or Red Supply Wire to:	Connect Black or White Supply Wire to:
Black Fixture Wire or	White Fixture Wire or
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black without tracer
Insulated wire (other than green) with copper conductor	Insulated wire (other than green) with silver conductor

*Note: When parallel wire (SPT 1 & SPT2) is used. One wire is square shaped or ridged and the other wire will be round in shape or smooth. (See Illustration)



- D) Connect ground wire from supply source to fixture ground wire with connector. Never connect ground wire to black or white power supply wires. Carefully place wires inside post.
- E) Slip post cup onto post. Align holes in post cup with holes in post. Attach post cup to post with post cup screws.