

Owner's Manual

STAINLESS STEEL

PROFESSIONAL

RANGE HOOD

IMPORTANT SAFETY INSTRUCTIONS

PLEASE READ ALL INSTRUCTION BEFORE USING

SAFETY PRECAUTIONS

WARNING! To reduce the risk of fire, electric shock or injury to persons, observe the following:

- A. Use this unit only in the manner intended by the manufacturer. If you have questions, please contact the manufacturer.
- B. Disconnect the electrical plug prior to any maintenance and cleaning.
- C. Do not use this unit with any solid-state speed control device
- D. This unit must be grounded.

Caution — This hood is for general ventilating use only. Do not use to exhaust hazardous or explosive materials and vapors.

To reduce the risk of injury to persons in the event of a range top grease fire, observe the following:

- A. Smother flames with a close-fitting lid, cookie sheet or metal tray, and then turn off the burner. **BE CAREFUL TO PREVENT BURNS.**
- B. If the flame do not go out immediately ,**EVACUATE AND CALL THE FIRE DEPARTMENT**
- C. **NEVER PICK UP A FLAMING PAN---**you may be burned
- D. **DO NOT USE WATER** including wet dishcloths or towels –a violent steam explosion will result.
- E. Use an extinguisher **ONLY** if:
 - 1. You know you have a class ABC extinguisher, and you already know how to operate it.
 - 2. The fire is small and contained in the area where is started
 - 3. The fire department is being called.
 - 4. You can fight the fire with your back to an exit.

Based on “Kitchen Fire Safety Tips” published by NFPA

WARNING---To reduce the risk of a range top grease fire:

- A. Never leave surface units unattended at high settings. Boilovers cause smoking and greasy spillovers that may ignite.
- B. Turn hood **ON** always when cooking at high heat or when cooking flaming foods
- C. Clean ventilating fans frequently. Grease should not be allowed to accumulate on fan or filter
- D. Use proper fan size. Always use cookware appropriate for the size of the surface element

Warning – To reduce the risk of fire, electric shock or injury to persons, observe the following:

- A. Installation work and electrical wiring must be done by qualified persons in accordance with all applicable codes and standards, including fire-related construction
- B. Sufficient air is needed for proper combustion and exhausting of gases through the flue (chimney) of fuel burning equipment to prevent back drafting. Follow the heating equipment manufacturer's guideline and safety standards such as those published by the National Fire Protection Association (NFPA), and the American Society for Heating, Refrigeration and Air Conditioning Engineers (ASHRAE), and the local code authorities.
- C. When cutting or drilling into wall or ceiling, do not damage electrical wiring and other hidden utilities.
- D. Ducted fans must always be vented to the outdoors.

Warning— To reduce the risk of fire, use only metal ductwork

- Do not attempt to repair or replace any part of your hood unless it is specifically recommended in this manual. All other servicing should be referred to a qualified technician.

Care and Cleaning

Baffle grease filters and drip trays

The metal baffles channel grease released by foods on the cook top into the trip trays. The baffles also help prevent flaming foods on the cook top from damaging the inside of the hood.

For this reason, the baffles must ALWAYS be in place when the hood is used. The grease baffles and drip trays should be cleaned once a month, or as needed.

To clean the grease baffles and drip trays,

Drain and wipe all excess grease with a dry paper towel, Soak them and then swish them around in hot water and detergent. Don't use ammonia or ammonia products because they will darken the metal. Do not use abrasives or oven cleaners. Rinse, shake and let them dry before replacing. **They may also be cleaned in an automatic dishwasher.**

To remove:


Grasp the baffle knobs and pull them up, forward and out. Grasp the drip tray and carefully lift it up and out of the hood track.

To replace the drip trays:

1. Place and seat the drip tray into the hood rack.
2. Slide them left and right until all trays are side-by-side in place in the track

To replace the baffles:

1. Hold the baffle by two knobs.
2. Place the up end of the baffle against the inside front of the hood.
3. Slide it up and push the bottom end back until it firmly seats into place



Stainless steel surface (on some models)

Do not use a steel-wool pad, it will scratch the surface.

1. Shake bottle well
2. Place a small amount of professional Stainless Steel Cleaning Polish and Conditioner on a dry cloth or dry paper towel.
3. Clean a small area rubbing with the grain of the stainless steel if applicable.
4. Repeat as necessary.

Light bulbs

The bulbs are located on the underside of the hood.

To change the light bulbs:

1. Grasp the bulb on the edges and remove by turning it anti-clockwise.
2. Replace with the same type and size of bulb

