




Pink Magnetic Upright Bike

Model No. P8200



IMPORTANT!

PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE BIKE.











For Customer Service, please contact: support@sunnyhealthfitness.com

Important Safety Information

We thank you for choosing our product. To ensure your safety and health, please use this equipment correctly. Please read the information below carefully before using this equipment.


1. It is important to read this entire manual before assembling and using the equipment. Safe and effective use can only be achieved if the equipment is assembled, maintained and used properly.
2. Before starting any exercise program you should consult your doctor to determine if you have any medical or physical conditions that could put your health and safety at risk, or prevent you from using the equipment properly. Your doctor's advice is essential if you are taking medication that affects your heart rate, blood pressure or cholesterol level.
3. Be aware of your body's signals. Incorrect or excessive exercise can damage your health. Stop exercising if you experience any of the following symptoms: pain, tightness in your chest, irregular heartbeat, extreme shortness of breath, lightheadedness, dizziness or feelings of nausea. If you do experience any of these conditions, you should consult your doctor before continuing with your exercise program.
4. Keep children and pets away from the equipment. The equipment is designed for adult use only.
5. Use the equipment on a solid, flat level surface with a protective cover for your floor or carpet. To ensure safety, the equipment should have at least 0.5 meters of free space all around it.
6. Before using the equipment, please make sure all the nuts and bolts are securely tightened. Always use the equipment as indicated. If you find any defective components while assembling or checking the equipment, or if you hear any unusual noises coming from the equipment during use, stop immediately. Do not use the equipment until the problem has been rectified.
7. There are many functions of the computer; the data will show when using the equipment and will display information about your exercise routine. Please note that the heart pulse monitor is solely to provide some reference.
8. Wear suitable clothing while using the equipment. Avoid wearing loose clothing that may get caught in the equipment or that may restrict or prevent movement.
9. The maximum weight of user: 220LBS.
10. Care must be taken when lifting or moving the equipment so as not to injure your back.
11. The equipment is not suitable for therapeutic use.
12. Please keep this manual and the assembling tools.
13. This equipment is designed for indoor and home use only, not intended for commercial use.

HARDWARE PACKAGE

	#34	M16*1.5*22	1PC
	#22	M8*60	4PCS
	#13	M8*30	2PCS
	#7	M8*16	4PCS
	#6	d8*Ø20*2*R30	8PCS
	#12	d8	2PCS
	#24	M8	4PCS
	#17		1PC
	37		
	36		

ASSEMBLY INSTRUCTIONS

Step 1:




A. Attach the Front stabilizer (23) and Rear stabilizer (26) to the Main frame (9) fixing with the 4 sets Carriage bolt (22), Arc-washers (6) and Nuts (24).

B. Attach the Pedals (25L/R) to the *left and right side of Crank (11).


* **IMPORTANT:** Left crank has reversed threading; you must screw pedal counter-clockwise to tighten. Failure to follow installation instructions may cause permanent damage to your bike.

Step 2:



Fix the Saddle (28) to the Saddle tube (31) with the Nylon nuts (30) and Washers (29).

Step 3:



A. Connect the bottom of the Tension control wire (10) with the Tension control (3) and connect the Sensor wire (8) with Trunk line (2).


***NOTE:** Please make sure the Tension control (3) is at the lowest tension level before you begin.

This will ensure the wires are at their longest reaching points to make the connection easier.

B. Insert the Handlebar post (5) to the Main frame (9) fixing with 4 sets Screws (7) and Arc-washers (6).

C. Attach the Stretch pipe (32) to the Saddle tube (31), then insert the Saddle tube (31) to the Main frame (9) fixing with Knob (34).

Step 4:



A. Connect the Computer wire (1a) with the Trunk line (2). Connect the Computer (1) to the top of Handlebar post (5).

B. Fix the Handlebar (20) to the Handlebar post (5) with the Screws (13) and Spring washer (12) and attach the Cover (17).

Assembly is complete.